
Troubleshooting: Is it the triac board or my wiring?



Troubleshooting: Is it the triac board or my wiring?

Removing the load wire from the output of the PCB20T6 triac board and touching it to the AC input side of the board jumpers out the triac and applies AC power to both sides of the load to verify if there is a wiring or defective load problem.

